

LESS PROBLEMS BY BETTER SERVICE! WE WILL HELP YOU!



IMPORTANT!

activate the service program regularly – we recommend at least once per week

SERVICE PROGRAM FOR DEHUMIDIFICATION OF THE VACUUM PUMP

During packaging water vapour might get into the vacuum pump. It deposits in the oil and can cause corrosion of the vacuum pump. If the service program is activated the pump is heated up in order to evaporate the water again. By means of the subsequent ventilation intervals the water vapour is blown out of the pump.

ATTENTION: The service program only serves to dehumidify the pump. It is still necessary to check the oil quality and the oil quantity and to perform an oil change, if required.

ACTIVATING THE SERVICE PROGRAM ON THE PERFECT AND SELECT CONTROL

It is possible to activate a service program to dehumidify the vacuum pump which heats up the pump in about 30 minutes to remove the condensed water from the oil. **Activating the service program:**

1

Make sure that the machine is switched off and the lid is opened.

2

Then simultaneously press the button ▲ and the button ▼ and keep both buttons pressed.

3

Switch on the machine while keeping the buttons pressed.

4

Close the lid of the vacuum chamber within 5 seconds and stop pressing the buttons.

5

The display now shows "SE" on the select control and "SEr" on the perfect control. The pump is vacuuming for about 5 minutes. Then the machine ventilates and vacuums in alternating intervals. The whole service program takes about 30 minutes.

6

Interrupting the service program:
It is possible to interrupt the service program at any time by pressing the VAC-STOP button. Then the machine runs in the working mode.

You may watch an animated film about the service program on our homepage www.vakuumpackaging.com under Packaging Solutions.